

DYM1074 (DT-810245) 40V Lithuim battery Lawnmmower part list(DT)

No	PN (Order:DYM1 454401/09110319 34)	Description(en)	Qty
1	26800601701	Bolt	4
2	26800800202	Spring washer	5
3	26800700201	Big washer	1
4	26300295101	Blade	1
5	25296000101	Blade support	1
6	23600301901	Wheel cover	2
7	26800502801	Nut	8
8	26800401601	Bearing	8
9	25400204001	Wheel assy	2
10	25287100101	Dustproof wheel cover	2
11	26800706202	Wave type washer	4
12	26800611901	Bolt	4
13	25315800101	Lower seat of wheel axle	2
14	25315900101	Upper seat of wheel axle	2
15	26300290101	Front wheel axle assy	1
16	26800500501	Nut	10
17	26800105402	Self driving screw	12
18	25318100101	Front decorative cover	1
19	25286500101	Side discharge cover board	1
20	26800201501	Trigger screw	2
21	26800800402	Spring washer	2
22	26300218303	Side discharge fixing board	1
23	26801113002	Side discharge spring	1
24	26200101901	Side discharge position fixing shaft	1
25	26800900201	Open block ring	4
26	26900300202	Right output gear assy	1
27	26809000102	Column pin	2
28	26800402301	Bearing	2

29	25254400102	Bearing seat	2
30	23050204901	Gear box assy	1
31	26300257701	Position fixing board	1
32	26800611201	Bolt	2
33	26900300102	Left output gear assy	1
34	25100201902	Triangle belt	1
35	26800201901	Trigger screw	6
36	26300124401	wheel axle fixing ring	2
37	26800502401	Nut	8
38	23600302001	Wheel cover	2
39	25400204101	Wheel assy	2
40	25229500101	Wheel gear ring	2
41	26800100501	Self0-driving screw	41
42	25208700105	11" dustproof wheel cover	2
43	26300289901	Rear wheel axle assy	1
44	26800903101	Elastic block ring for shaft	2
45	26800203001	Screw	2
46	25400113501	Height adjustmebnt handle assy	1
47	26800303301	Screw	2
48	26300314501	Handle assy	1
49	26300290601	Height adjustment board	1
50	23601043501	Deck	1
51	26800100302	Self-driving screw	10
52	25226000101	Cable pressing board bracket	1
53	25249100102	Cable pressing board	2
54	25217800104	Cable protection sheath	1
55	26300290201	Connection rod	1
56	26801103903	Connection rod spring	1
57	25248900201	Right window inlet board	1
58	25248900101	Left window inlet board	1
59	26800105502	Self-driving screw	5
60	27100118101	Battery male terminal welding wire	2
61	25337900201	Motor cover seat	1
62	25228400102	Cable connection protection sheath 2	1


63	H21300101301	Battery pack	2
64	25328700101	Switch pressing board	1
65	27600103501	Key switch	1
66	23001411101	Key pack	1
67	25337800201	Handle of motor cover	1
68	25338500101	Button seat	1
69	26801100301	Spring of safety button	1
70	25338400101	Side block of button	1
71	25338300201	Button	1
72	25337700101	Upper cover of battery	1
73	26800307801	Self- driving locking screw	2
74	25338200101	Lower protecting cover of belt	1
75	23057002801	Controller	1
76	28600103101	Control board of battery pack change	1
77	26801128501	Spring of battery bin	2
78	26800500801	Hex locking nut	4
79	25338000101	Motor bracket	1
80	26800601001	Bolt	4
81	26800309701	Self-driving screw	4
82	26800701201	Washer	3
83	26800100302	Self-driving screw	3
84	27400101701	Direct current Motor	1
85	26809003701	Flat key	1
86	25316400101	Driving belt wheel	1
87	26800902601	Elastic block ring for shaft	1
88	25338100101	Belt protection cover	1
89	26800500701	Hex nut	4
90	25236503201	Knob of lower handle	4
91	26800700701	Flat washer	6
92	26800606401	Bolt	4
93	23601043601	Left handle support	1
94	23601008701	Lower handle	1
95	26800611802	Bolt	2
96	23601043701	Right handle support	1

97	25261100101	Cable clamp	2
98	25100108501	Curve washer	2
99	29100135601	Driving cable	1
100	23601035801	Upper handle	2
101	26800607701	Bolt	1
102	25233600101	Fixing block of cord	1
103	26800700801	Flat washer	5
104	26800501603	Lid shape nut	1
105	25339200101	Lower cover of left handle sheath	1
106	26800502201	Nut	2
107	25339300101	left side handle sheath upper cover	1
108	26800315001	Screw	2
109	25339500101	Left bracket of driving pole	1
110	25339800101	Haning block of self-propelled cable	2
111	25339700101	Driving pole bracket cover board	2
112	26800103701	Self-driving screw	2
113	25339600101	Right bracket of driving pole	1
114	25338800202	Lower side button	2
115	25338900201	Upper side button	2
116	26801126601	Spring	9
117	25400112201	Rubber wrap of lower cover of handle panel	1
118	27100118401	Switch wire of handle	1
119	28600103001	Display board of battery	1
120	25400112101	Rubber wrap of upper cover of handle panel	1
121	23601044501	Driving pole	1
122	26800104902	Self-driving screw	2
123	25339100101	Upper cover of handle switch box	1
124	25339400201	Button of handle touching	1
125	25339000101	Lower cover of handle switch box	1
126	27100118301	Control wire of handle	1
127	26800613001	Flat head bolt	2
128	25232600101	Mulching kit	1
129	25231600801	Button of mulching kit	1
130	26801100501	Spring	2

131	25231700101	Pressed board of button	1
132	25316700101	Handle of grass catcher	1
133	25316600101	Upper cover of grass catcher	1
134	25275602301	Level indicator	1
135	25316500401	Rear cover	1
136	25100137801	Grass bag	1
137	26800103202	Self-driving screw	2
138	26801125501	Right rotation spring	1
139	26300281401	Long pole	1
140	26800104601	Self-driving screw	1
141	26300195901	Bracket of grass bag	1
142	26801125401	Left rotation spring	1
143	25306600101	Side discharge protecting cover	1
144	22600100601	Charger	1

由 Autodesk 教育版产品制作

由 Autodesk 教育版产品制作



借通用件登记
描图
校描
旧底图总号
F
签字
日期

DYM1074爆炸图			
标记	处数	更改文件号	签字
设计		标准化	
审核		日期	
工艺			
共 页		重量	比例
		14683	1:1
第 页		第 页	